



Stihl 14" Corded Chainsaw - MSE 210 C-B

This powerful electric chainsaw provides professional performance with a minimal carbon footprint.

[Read More](#)

SKU: MSE-210-CB

Categories: [STIHL](#)

Product Description

Features

STIHL Electric Motor -Maintenance-free brushless DC motor features low noise levels and reduced vibration.

Quick Chain Adjuster (QCA) (B) -The Quick Chain Adjuster (QCA) (B) allows the user to adjust the tension of the chain without the use of tools. This allows for easy chain adjustment.

Lightweight Portability -This product is lightweight for easy portability, great maneuverability, and extended use.

Compact, Ergonomic Design -The compact, ergonomic design provides more comfortable use.

Soft-Grip Handle -This handle design provides a secure and comfortable grip.

Throttle Trigger Interlock -This safety feature must be depressed before the trigger can be activated.

STIHL Quickstop® -STIHL chainsaws are equipped with a chain stopping system designed to reduce the risk of injury in certain kickback situations. It is called a STIHL Quickstop® chain brake. The STIHL Quickstop® chain brake is designed to stop the rotation of the chain if activated by the operator's hand or by inertia if the saw kicks back with sufficient force. In some working positions, the STIHL Quickstop® chain brake can be activated by inertia, stopping the chain within fractions of a second.

Warnings and Safety

IMPORTANT SAFETY INFORMATION The occurrence called "kickback" can cause serious or fatal injury. Always read the instruction manual carefully before using your saw. STIHL uses a green and yellow color-coding system to help you select a powerhead, bar and chain combination that complies with the kickback requirements of ANSI Standard B175.1 (gasoline-powered saws) and §30 of UL 1662/ ANSI Standard B175.1 (electric chainsaws). Ask your STIHL dealer about safe operating procedures and the advantages of the STIHL Quickstop® chain brake, STIHL Quickstop® Plus additional chain braking feature, STIHL reduced kickback bars and STIHL low-kickback saw chains. STIHL recommends the use of green reduced kickback bars and green low kickback chains on all STIHL chainsaws.

WARNING FOR CORDED-ELECTRIC USERS! STIHL recommends that leg protection be worn when operating corded electric chainsaws. However, the fibers may not stop the sprocket on most corded electric chainsaws because of the constant high torque.

* The actual listed guide bar length can vary from the effective cutting length based on which powerhead it is installed on.

WARNING! Improper use of any power tool may cause serious or fatal injury. Read, understand, and follow carefully the operating and safety instructions in your instruction manual before using such products. STIHL products sold through U.S. STIHL Dealers are for distribution in the United States only.

WARNING! Improper use of any power tool may cause serious or fatal injury. Read, understand, and follow carefully the operating and safety instructions in your instruction manual before using such products.

STIHL products sold through U.S. STIHL Dealers are for distribution in the United States only.
